


# :Catálogo



# FERVE

THE BATTERY LIFE

## 2024



VIEIRA & FREITAS LDA.

F 500 70 003



BOOSTER MINI FERVE 300A 12V  
5400mAh

F 505 70 003



BOOSTER BOX FERVE 400A 12/19V  
5/12/19V 12000mAh = 02524

F 515 70 003



BOOSTER EDLC 500A 12V  
S/BATERIA - SUPERCONDENSADOR

X 505BC 70 003



GARRAS P/BOOSTER F-505

F 1 70 007



ADAPTADOR FERVE ISQUEIRO USB  
12 / 24V para 5V 1 Amp

F 30 70 007



PONTA PROVAS CIRCUITOS FERVE  
2.8V a 48 Volts Electronica

F 45 70 007



COMPROVADOR DE BATERIA  
LIGAR AO ISQUEIRO F.P.

F 85 70 007



TESTADOR SISTEMA ELECTRICO FERVE  
12V Regulador/Alt./Bater. c/leds

F 90 70 007



TESTADOR SISTEMA ELECTRICO FERVE  
12-24V - Bateria/ALT. Com Leds

F 219 70 007



CARREGADOR P/F2000 12V 2A  
100/240V 5/60HZ 30W

F 502 70 007



FICHA OBD P/ F-505

F 705 70 007



CARREGADOR BATERIAS FERVE 6/12V  
6-12V 1,5-5 AMP - AUTO/MOTO

F 807 70 007



CARREGADOR BATERIAS FERVE  
12/24V-4/8AMP 24-120 Ah

F 812 70 007



CARREG./TESTADOR BATERIAS FERVE  
12/24V 6-12 AMP. Voltim./amper.

F 814 70 007



COMPROVADOR BATERIAS DI-  
12V DESCARGA 250A C/pico

F 903 70 007



CARREGADOR BATERIAS FERVE 12V  
5 AMP. - 12V

F 905 70 007



CARREGADOR BATERIAS FERVE 12V  
= F-50

F 908 70 007



CARREGADOR BATERIAS FERVE DUAL  
MANUAL/AUT. 12V 24-120 Ah

F 909 70 007



CARREGADOR BATERIAS FERVE  
AUTOMATICO - 12-24V 8 AMP.

F 915 70 007



CARREG./TESTADOR BATERIAS FERVE  
12/24V 7-15 AMP. Voltim./amperim

F 916 70 007



PONTA PROVAS CIRCUITOS FERVE  
6-12-24 Volts P/Neg. ELECTRONICO

F 925 70 007



CARREGADOR/ TESTE BATERIAS FERVE  
12/24V 55/35A Booster 250A

F 968 70 007



CARREGADOR BATERIAS 6-12V 4-8A  
115W 24-95Ah

F 970 70 007



CARREGADOR BATERIA BOOSTER FER-  
C/CARRINHO e TELECOMANDO - 450A

F MR1 70 007




RETIFICADOR BATERIA

F R11 70 007



RETIFICADOR CORRENTE FERVE  
P/F806/F915

F R21 70 007



RETIFICADOR CORRENTE FERVE

F 1707 70 007




COMPROVADOR CORRENTE DIG.  
AMP-MULTIMETRO C/PINCAS

**F 1810** 70 007



**TESTADOR BATERIAS C/IMPRESSAO  
12/24V ALTA PRECISAO**

**F 1830** 70 007



**MULTIMETRO DIGITAL FERVE 0-600V  
DC/AC VOLTS DC/AC AMP. OHMs**

**F 1880** 70 007



**MULTIMETRO DIGITAL C/USB  
1000V C/SENSOR TEMP.**

**F 1902** 70 007



**TESTADOR SIST. ELECTRICO DIGITAL  
25-200Ah**

**F 2200** 70 007



**PONTA PROVAS VOLTIMETRO DIGITAL  
12V/24V FERVE**

**F 2201** 70 007




**CARREGADOR BATERIAS 12V 750mA  
20W 4-45Ah AUTOM. =02088**

**F 2316** 70 007



**CARREGADOR BATERIAS FERVE DUAL  
12/24V 35-140Ah TEST / AUTOM.**

**F 2400** 70 007



**TESTADOR BATERIAS 12/24V  
CARREGAR ISQUEIRO**

**F 2504** 70 007




**CARREGADOR BATERIAS AUTOMAT.  
12V 1.2=>120Ah =F2505 F.P.**

**F 2505** 70 007



**CARREGADOR BATERIAS FERVE  
6-12V 2-4A**

**F 2507** 70 007



**CARREGADOR BATERIAS 12V 135W  
7A 14-230Ah**

**F 2908** 70 007



**CARREGADOR BATERIA FERVE TETRA  
12-24V 24A 95Ah**

**F 2916** 70 007



**CARREGADOR BATERIAS FERVE 12/24V  
TETRA 50-180Ah 8/16 Amp - AUTOM.**

**F 2920** 70 007



**CARREGADOR BATERIAS FERVE 12/24V  
TETRA 80-225Ah 10/20 Amp. AUTOM**

**F 2930** 70 007



**CARREGADOR BATERIAS FERVE 12/24V  
TETRA 105-360Ah 15/30 amp. AUTOM**

**F 3020** 70 007



**CARREGADOR BATERIAS 12V 360W  
20A 45-225Ah ##**

**F 9030** 70 007



**CARREGADOR BAT FONTE ALIM. TESTE  
FERVE AUT. 5/10/20/30A univ.**

**F 9050** 70 007



**CARREGADOR BAT. FONTE ALIMENTA-  
FERVE AUTOMATICO 12V 1 - 50A**

**F 9100** 70 007



**CARR. BAT. E FONTE ALIMENT 100A  
TESTE ALT 12V - 5A a 100A FERVE**

**F 9200** 70 007



**CARREGADOR/BOOSTER FERVE 12V  
BOOSTER 600A**

**F 4808L** 70 007



**CARREGADOR BATERIA 48V 8A**

**F 205** 70 065



**CABO REPARACAO P/F9100**

**F 211** 70 065



**ADAPTADOR ISQUEIRO P/ F2201  
300mm**

**F 214** 70 065



**FICHA USB P/F2201  
315mm**

**F 216** 70 065



**CONECTOR FICHA TERMINAL OLHAL  
P/ F2201 F2505 F2705**

**F 217** 70 065



**CONECTOR FICHA TERMINAIS  
P/ F2201 F2505 F2507**

**F 220** 70 065



**CABO C/TREMINAIS P/F-2504/F-2507**

**F 402** 70 065



**PINCAS DE BATERIA FERVE PAR  
PAR- 50mm - 10 AMP.**

F 410 70 065



PINCAS DE BATERIA FERVE PAR SACO 1 JOGO - 25 AMP.- 175x110mm

F 423 70 065



DENSIMETRO PRECISAO FERVE MINI 210mm Blister

F 600 70 065



GARRAS DE BATERIA FERVE 600 AMP. PAR

F 1025 70 065



CAIXA DE FERRAMENTAS BOLSO

F 1822 70 065



CONECTOR PINCAS SUPORTES P/ F1830 F1880 F1707 F1708

F 425C 70 065



DENSIMETRO ALTA PRECISAO FERVE 245mm

F 954 70 065



PICA FIOS FERVE VERIFICADOR DE CORRENTE

F 416 12 70 065



BUSCA POLOS FERVE C/lampada 12V Com Fio e Garra