


# :Catálogo

# FERVE

THE BATTERY LIFE



# 2025



VIEIRA & FREITAS LDA.

F 1 70 007



ADAPTADOR FERVE ISQUEIRO USB  
12 / 24V para 5V 1 Amp

F 30 70 007



PONTA PROVAS CIRCUITOS FERVE  
2.8V a 48 Volts Electronica

F 45 70 007



COMPROVADOR DE BATERIA F.P  
LIGAR AO ISQUEIRO

F 85 70 007



TESTADOR SISTEMA ELECTRICO FERVE  
12V Regulador/Alt./Bater. c/leds

F 90 70 007



TESTADOR SISTEMA ELECTRICO FERVE  
12-24V - Bateria/ALT. Com Leds

F 205 70 065



CABO REPARACAO P/F9100

F 211 70 065



ADAPTADOR ISQUEIRO P/ F2201  
300mm

F 214 70 065



FICHA USB P/F2201  
315mm

F 216 70 065



CONECTOR FICHA TERMINAL OLHAL  
P/ F2201 F2505 F2705

F 217 70 065



CONECTOR FICHA TERMINAIS  
P/ F2201 F2505 F2507

F 219 70 007



CARREGADOR P/F2000 12V 2A  
100/240V 5/60HZ 30W

F 220 70 065



CABO C/TREMINAIS P/F-2504/F-2507

F 402 70 065



PINCAS DE BATERIA FERVE PAR  
PAR- 50mm - 10 AMP.

F 410 70 065



PINCAS DE BATERIA FERVE PAR  
SACO 1 JOGO - 25 AMP.- 175x110mm

F 423 70 065




DENSIMETRO PRECISAO FERVE MINI  
210mm Blister

F 500 70 003




BOOSTER MINI FERVE 300A 12V  
5400mAh

F 502 70 007



FICHA OBD P/ F-505

F 505 70 003



BOOSTER BOX FERVE 400A 12/19V  
5/12/19V 12000mAh =02524

F 515 70 003



BOOSTER EDLC 500A 12V  
S/BATERIA - SUPERCONDENSADOR

F 600 70 065



GARRAS DE BATERIA FERVE 600 AMP.  
PAR

F 705 70 007



CARREGADOR BATERIAS FERVE 6/12V  
6-12V 1,5-5 AMP - AUTO/MOTO

F 807 70 007



CARREGADOR BATERIAS FERVE  
12/24V-4/8AMP 24-120 Ah

F 812 70 007



CARREG./TESTADOR BATERIAS FERVE  
12/24V 6-12 AMP. Voltim./amper.

F 814 70 007



COMPROVADOR BATERIAS DI-  
12V DESCARGA 250A C/pico

F 903 70 007



CARREGADOR BATERIAS FERVE 12V  
5 AMP. - 12V

F 905 70 007



CARREGADOR BATERIAS FERVE 12V  
= F-50

F 908 70 007



CARREGADOR BATERIAS FERVE DUAL  
MANUAL/AUT. 12V 24-120 Ah

F 909 70 007



CARREGADOR BATERIAS FERVE  
AUTOMATICO - 12-24V 8 AMP.

F 915 70 007



CARREG./TESTEDOR BATERIAS FERVE 12/24V 7-15 AMP. Voltim./amperim

F 916 70 007



PONTA PROVAS CIRCUITOS FERVE 6-12-24 Volts P/Neg. ELECTRONICO

F 925 70 007



CARREGADOR/ TESTE BATERIAS FERVE 12/24V 55/35A Booster 250A

F 968 70 007



CARREGADOR BATERIAS 6-12V 4-8A 115W 24-95Ah

F 970 70 007



CARREGADOR BATERIA BOOSTER ### C/CARRINHO e TELECOMANDO - 450A

F MR1 70 007



RETIFICADOR BATERIA

F R11 70 007



RETIFICADOR CORRENTE FERVE P/F806/F915

F R21 70 007



RETIFICADOR CORRENTE FERVE

F 1025 70 065



CAIXA DE FERRAMENTAS BOLSO

F 1707 70 007



COMPROVADOR CORRENTE DIG. AMP-MULTIMETRO C/PINCAS

F 1810 70 007



TESTADOR BATERIAS C/IMPRESSAO 12/24V ALTA PRECISAO

F 1822 70 065



CONECTOR PINCAS SUPORTES P/ F1830 F1880 F1707 F1708

F 1830 70 007



MULTIMETRO DIGITAL FERVE 0-600V DC/AC VOLTS DC/AC AMP. OHMs

F 1880 70 007



MULTIMETRO DIGITAL C/USB 1000V C/SENSOR TEMP.

F 1902 70 007



TESTADOR SIST. ELECTRICO DIGITAL 25-200Ah

F 2200 70 007



PONTA PROVAS VOLTIMETRO DIGITAL 12V/24V FERVE

F 2201 70 007



CARREGADOR BATERIAS 12V 750mA 20W 4-45Ah AUTOM. =02088

F 2316 70 007



CARREGADOR BATERIAS FERVE DUAL 12/24V 35-140Ah TEST / AUTOM.

F 2400 70 007



TESTADOR BATERIAS 12/24V CARREGAR ISQUEIRO

F 2504 70 007



CARREGADOR BATERIAS AUTOMAT. 12V 1.2=>120Ah =F2505 65W

F 2505 70 007



CARREGADOR BATERIAS FERVE 6-12V 2-4A

F 2507 70 007



CARREGADOR BATERIAS 12V 135W 7A 14-230Ah

F 2510 70 007



CARREGADOR BATERIA 12V F.P =F9012 =

F 2908 70 007



CARREGADOR BATERIA FERVE TETRA 12-24V 24A 95Ah

F 2916 70 007



CARREGADOR BATERIAS FERVE 12/24V TETRA 50-180Ah 8/16 Amp - AUTOM.

F 2920 70 007



CARREGADOR BATERIAS FERVE 12/24V TETRA 80-225Ah 10/20 Amp. AUTOM

F 2930 70 007



CARREGADOR BATERIAS FERVE 12/24V TETRA 105-360Ah 15/30 amp. AUTOM

F 3020 70 007



CARREGADOR BATERIAS 12V 360W 20A 45-225Ah ##

F 425C 70 065



DENSIMETRO ALTA PRECISAO FERVE  
245mm

F 9012 70 007



CARREGADOR BATERIA 6-12V

F 9030 70 007



CARREGADOR BAT FONTE ALIM. TESTE  
FERVE AUT. 5/10/20/30A univ.

F 9050 70 007



CARREGADOR BAT. FONTE ALIMENTA-  
FERVE AUTOMATICO 12V 1 - 50A

F 9100 70 007



CARR. BAT. E FONTE ALIMENT 100A  
TESTE ALT 12V - 5A a 100A FERVE

F 9200 70 007




CARREGADOR/BOOSTER FERVE 12V  
BOOSTER 600A

F 95/4 70 065



PICA FIOS FERVE  
VERIFICADOR DE CORRENTE

F 4808L 70 007



CARREGADOR BATERIA 48V 8A

F 416 12 70 065



BUSCA POLOS FERVE C/lampada 12V  
Com Fio e Garra

X 505BC 70 003



GARRAS P/BOOSTER F-505