

:Catálogo



2025



VIEIRA & FREITAS LDA.

113000 26 040

FICHA DE ISQUEIRO MACHO
 = 180113 - MACHO

113202 26 040

FICHA DE ISQUEIRO MACHO
 = 180230 = 6815.00 = 2522000

114320 26 040

FICHA FEMEA p/ TABELIER c/ TAMPA
 = 060798

135010 26 046


CAIXA PORTA 2 FUSIVEIS
 Plastica = 260100

135110 26 046

CAIXA PORTA 4 FUSIVEIS
 Plastica = 190770 = 260101

135210 26 046

CAIXA PORTA 6 FUSIVEIS
 Plastica = 190772 = 260103

135310 26 046

CAIXA PORTA 8 FUSIVEIS
 Plastica = 260104

201000 26 052

INTERRUPTOR BOTAO de ARRANQUE
 = 63190 = 030105

201400 26 052

INTERRUPTOR BOTAO UNIVERSAL
 22mm cromado

201600 26 052

INTERRUPTOR BOTAO de ARRANQUE
 = 63300 C/ BORRACHA = 030302

201700 26 052

INTERRUPTOR UNIVERSAL ANTI AGUA
 22mm 24V 200W

202500 26 052

INTERRUPTOR BOTAO 15mm
 Preto = 180400 = 030210

202800 26 052

INTERRUPTOR PRESSAO UNIVERSAL
 22.5mm metal

203100 26 052

INTERRUPTOR PRESSAO 22.5mm
 24v 200w metal

206020 26 052

INTERRUPTOR SENSOR PORTA
 1 terminal

206250 26 052

INTERRUPTOR SENSOR PORTA
 2mm

206520 26 052

INTERRUPTOR SENSOR PORTA
 2 terminais

206550 26 052

INTERRUPTOR SENSOR CAPOT
 UNIVERSAL

210020 26 052

INTERRUPTOR de PUXAR CURTO
 em METAL = 180103 = 010101

210620 26 052

INTERRUPTOR PUXAR CURTO ON/OFF
 METAL =180103

210720 26 052

INTERRUPTOR PUXAR CURTO
 terminais =180103

211020 26 052

INTERRUPTOR PUXAR COMPRIDO
 METAL =180104 =010201=0986340001

211620 26 052

INTERRUPTOR PUXAR COMPRIDO
 LIG. parafusos

211720 26 052

INTERRUPTOR PRESSAO UNIVERSAL
 metal lig.parafusos

215000 26 052

INTERRUPTOR ALAVANCA ON-OFF
 REFORCADO

215700 26 052

INTERRUPTOR ALAVANCA COMPRIDO
 12V 75W DIN46 ON/OFF

216001 26 052

INTERRUPTOR ALAVANCA CURTA
 12V 75W DIN 46

219402 26 052

INTERRUPTOR PUXAR LARANJA

219412 26 052

INTERRUPTOR PUXAR VERDE
219422 26 052

INTERRUPTOR PUXAR VERMELHO
252315 26 040

CONECTOR INTERRUPTOR REDONDO MERIT 7 POLOS s/terminais
270770 26 055

LAMPADA 12V P/ INTERRUPTOR ME- P/ TRATORES
270771 26 055

LAMPADA 24V P/INTERRUPTOR ME- P/ TRATORES
320000 26 052

INTERRUPTOR LUZES de PUXAR 2Posicoes =180010 =010501 =23848
320100 26 052

INTERRUPTOR LUZES de PUXAR C/FUS 2 POSICOES = 010502
321400 26 052

INTERRUPTOR de LUZES P/ TRACTOR 3 POSICOES = 180158 = 012022
322100 26 052

INTERRUPTOR de PE P/LUZES COMUTADOR Max/Min lig:parafusos
322200 26 052

INTERRUPTOR de PE P/LUZES lig: terminais 12V 100W
324100 26 052

INTERRUPTOR ALAVANCA CURTO 3lig parafuso ON/OFF/ON
324200 26 052

INTERRUPTOR ALAVANCA CURTO PRE- ON-OFF-ON 3 terminais
324500 26 052

INTERRUPTOR ALAVANCA ALUMINIO ON-OFF-ON 3lig parafusos
325000 26 052

INTERRUPTOR PISCAS TRACTOR = 180007 = 230119
325202 26 052

INTERRUPTOR PISCAS P/ TRACTOR Com Luz Verde
325302 26 052

INTERRUPTOR INDICADOR LUMINOSO VERDE 12V
325400 26 052

INTERRUPTOR ALAVANCA PRETO 12/24V 75W
325602 26 052

INTERRUPTOR PISCAS VOLANTE VERDE C/ LUZ = 180039
327000 26 082

INTERRUPTOR IGNICAO 4 TERMINAIS
327200 26 082

INTERRUPTOR DE SEGURANCA CHAVE C/ SAIDA EM 2 POSICOES
327300 26 052

INTERRUPTOR IGNICAO =ISC7 =180027 =230105 =22150002
327550 26 052

INTERRUPTOR IGNICAO + CHAVE
328600 26 052

INTERRUPTOR CORTE GERAL ALAVAN- C/ 2 CIRCUITOS = 180596
330262 26 052

INTERRUPTOR CORTE IGNICAO C/AQUECIMENTO =180044UN
514102 26 052

INTERRUPTOR TRACTOR ON/OFF LUZ TRASEIRA 4 TERM. AMARELO
514103 26 052

INTERRUPTOR TRACTOR ON/OFF VENTONINHA 4 TERM. AMARELO
515301 26 052

INTERRUPTOR REDONDO LUZES
516103 26 052

INTERRUPTOR TRACTOR ON/OFF LUZ FRENTE 6 TERM. AMARELO

516104 26 052



INTERRUPTOR TRACTOR ON/OFF LUZ ROTATIVA 6 TERM. AMARELO

516109 26 052



INTERRUPTOR TRACTOR ON/OFF COMANDO VEIO PTO 6 TERM. VERM.

517201 26 052



INTERRUPTOR REDONDO STOP

535101 26 052



INTERRUPTOR REDONDO L/VIDROS

544101 26 052



INTERRUPTOR REDONDO ESGUICHO ESGUICHO LIMPA VIDROS

738100 26 052



AVISO TABLIER AZUL terminais

738500 26 052



AVISO TABLIER VERDE terminais

516106 26 052



INTERRUPTOR TRACTOR ON/OFF ACESSORIOS 6 TERM. AMARELO

516202 26 052



INTERRUPTOR TRACTOR ON/OFF DESLIGA MOTOR 6 TERM. VERMELHO

517202 26 052



INTERRUPTOR TRACTOR ON/OFF PERIGO 4 PISCAS 7 TERM. =181256

542102 26 052



INTERRUPTOR TRACTOR PUSH BUZINA 2 TERM. AMARELO

544102 26 052



INTERRUPTOR REDONDO POSICAO SUBIR BAIXAR

738200 26 052



AVISO TABLIER AMARELO = 98615 = 040428

738600 26 052



AVISO TABLIER VERMELHO = 98613 = 040402

516107 26 052



INTERRUPTOR TRACTOR ON/OFF DIFERENCIAL 6 TERM. AMARELO

517101 26 052



INTERRUPTOR TRACTOR ON/OFF COMANDO VEIO PTO 7 =542103

524102 26 052



INTERRUPTOR REDONDO ROTATIVO FAROL ROTATIVO =181252

542103 26 052



INTERRUPTOR REDONDO 517101fp

544103 26 052



INTERRUPTOR TRACTOR PUSH START 4 TERM. AMARELO

738300 26 052



AVISO TABLIER LARANJA terminais

516108 26 052



INTERRUPTOR TRACTOR ON/OFF TRACCAO 4 RODAS - 6 TERM.

517102 26 052



INTERRUPTOR TRACTOR ON/OFF ESCIVAS L/V 7 TERM. AMARELO

534201 26 052



INTERRUPTOR TRACTOR ON/OFF COMANDO VEIO PTO 4 TERM. VERM.

542401 26 052



INTERRUPTOR TRACTOR PUSH RESET 2 TERM. VERDE

738000 26 052



AVISO TABLIER AZUL parafusos = 98616 = 040425

738400 26 052



AVISO TABLIER VERDE = 98614 = 040422